



Watch our installation
instruction video
Olmeck.com/patchkit

Lava 20 Detail Repair Kit

- Integrated Fleece Technology
- Durable and Long-Lasting
- User-Friendly Application
- Weather-Resistant almost immediately
- Single-Coat Coverage



KIT INCLUDES:

• **Lava 20 Detail**
6 kg / 13.23 lbs. / 1.56gal



• **Fast Primer**
.075 kg / 1.65 lbs / 0.195 gal



• **PU Mastic**
300 ml / 0.6651 lb / 0.0792 gal



• **1 Mixing Stick**



• **2 Brushes**



• **2 Gloves**



• **1 Can Opener**



Installation Instructions:

Preparation

Monitor the Weather

- Ensure you have a few hours of nice weather before starting the repair.

Ensure Safety

- Create a safe working environment by securing ladders and using safety harnesses if necessary.

Clean the Patch Area

- Remove oil, grease, and debris from the area to be patched.
- Ensure the surface is completely clean.

Dry the Surface

- Before applying the primer, make sure the area is completely dry.

Tape the Patch Area

- Apply adhesive tape around the patch area for a neat and tidy job.

Application

Prepare the Primer:

- Shake the primer well.
- Pour the primer into a paint tray.

Apply the Primer:

- Apply a thin coat of Lava 20 Fast Primer, covering the entire area.
- Do not apply a thick coat.

Wait for the Primer to Dry:

- Allow the primer to dry completely for 15 to 20 minutes.

Mix the Lava 20 Detail:

- Use the mixing stick to stir the Lava 20 Detail thoroughly.
- Ensure the fleece pieces at the bottom of the can are well mixed into the liquid.

Apply the Lava 20 Detail:

- Apply a coat of Lava 20 Detail, covering the entire patch area.

Remove the Tape:

- Carefully take off the adhesive tape.



Regardez notre vidéo
d'instructions d'installation

[Olmeck.com/patchkit](https://olmeck.com/patchkit)

Kit De Réparation Lava 20 Detail

- Technologie de Fleece Intégrée
- Durable et Longue Durée
- Application Facile à Utiliser
- Résistant aux Intempéries Presque Immédiatement
- Couverture en Une Seule Couche



KIT INCLUDES:

- **Lava 20 Detail**
6 kg / 13.23 lbs. / 1.56gal
- **Fast Primer**
.075 kg / 1.65 lbs / 0.195 gal
- **PU Mastic**
300 ml / 0.6651 lb / 0.0792 gal
- 1 Bâton pour mélanger la peinture
- 2 Pinceaux
- 2 Gants
- 1 Ouvre-boîte



Instructions d'Installation :

Préparation de l'Application

Surveillez la Météo:

- Assurez-vous d'avoir quelques heures de beau temps avant de commencer la réparation.

Assurez la Sécurité:

- Créez un environnement de travail sûr en sécurisant les échelles et en utilisant des harnais de sécurité si nécessaire.

Nettoyez la Zone à Réparer:

- Enlevez l'huile, la graisse et les débris de la zone à réparer.
- Assurez-vous que la surface est complètement propre.

Séchez la Surface:

- Avant d'appliquer l'apprêt, assurez-vous que la zone est complètement sèche.

Scotchez la Zone à Réparer:

- Appliquez du ruban adhésif autour de la zone à réparer pour un travail propre et soigné.

Application

Préparez l'Apprêt:

- Agitez bien l'apprêt. Versez l'apprêt dans un bac à peinture.

Appliquez l'Apprêt:

- Appliquez une fine couche de Lava 20 Fast Primer, en couvrant toute la zone.
- Ne pas appliquer une couche épaisse.

Laissez Sécher l'Apprêt:

- Laissez l'apprêt sécher complètement pendant 15 à 20 minutes.

Mélangez le Lava 20 Detail:

- Utilisez le bâton de mélange pour bien remuer le Lava 20 Detail.
- Assurez-vous que les morceaux de fleece au fond de la boîte sont bien mélangés au liquide.

Appliquez le Lava 20 Detail:

- Appliquez une couche de Lava 20 Detail, en couvrant toute la zone à réparer.

Retirez le Ruban Adhésif:

- Retirez soigneusement le ruban adhésif.